


## **SV168 Series Range Hoods- Light Bulb Replacement**

This range hood may require two or four halogen bulbs (Type JCD, 12V, 20W Max, G-4 Base)

**WARNING:** Always switch off the electrical supply before carrying out any operation on the appliance.

To change bulbs:

1. Remove the halogen bulb cover ② by using the flat screw driver.
2. Remove the bulb by pulling sideward (DO NOT ROTATE).
3. Replace with Type JCD, 12V, 20W Max, G-4 Base halogen bulb. Do not touch replacement bulb with bare hands!



### **CAUTION:**

1. **THE SURFACE, THE COVER OF THE HALOGEN BULBS MAY BE HOT. TAKE CARE WHEN TAKING THE REPLACEMENT.**
2. **BULBS MAY BE HOT. TAKE CARE WHEN TAKING THE REPLACEMENT.**